



INSTALL BY POSITIONING BIN FRONT BEHIND THE FACE OF THE POST AS SHOWN ABOVE. TO FASTEN ALIGN BOTTOM OF THE BIN FRONT LIP WITH THE HOLES LOCATED IN THE FACE OF THE SHELF AND USE (3) PANEL CLIPS.

